



# Motorola Buzz ic502 SIM card Replacement

No tools are necessary, simply be careful of where you touch the SIM card

Written By: Austin Quinn



## INTRODUCTION

In this guide, the user will learn where the SIM card is and how to remove it.

## Step 1 — Battery



- First flip the phone over.
- Then find the back release circled in red.

## Step 2



- Carefully remove the back using the release.
- Lift from the bottom!



### Step 3



- Lift the battery from the right side.
- After the battery has lifted about a 45 degree angle remove from phone.

### Step 4 — SIM card



- The SIM card is located here
- Carefully push the SIM card down from the top with your finger
- Make sure to hold card from sides and do not touch the marked spot on card

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 03:11:55 AM.